

Thank you for purchasing a National Cycle product. Read these instructions carefully and thoroughly before beginning work. Dealers, if installing this windscreen for a customer, please give them this manual upon completion. It contains information needed to properly maintain and use this product.



Attention:

Special notes and cautionary measures which can prevent damage to the accessory or motorcycle.





Note:

Tips for facilitation of operation, control and adjustment, as well as maintenance work.

CONTENTS OF KIT

Item	Description	Part No.	Qty.	Notes and Tools
(1)	VStream® Windscreen		1	
Bag#1285				
(2)	Rubber Grommet	44-447350-000	4	
(3)	Cap, Aluminum, Black	34-346047-000	4	
(4)	Screw, Flat, M6 x 40, SS	51-514240-000	4	4mm Hex Wrench
(5)	Bushing, .847 L, Upper	49-495283-000	2	
(6)	Bushing 1.049 L, Lower	49-495284-000	2	



TOOLS

5mm Hex Wrench

4mm Hex Wrench



Figure 1

PREPARATION

1. Position motorcycle securely on its stand. Remove the OEM windscreen. The stock hardware will not be re-used. (5mm Hex Wrench) **Figure 1**



Figure 4



Figure 4




Figure 4

INSTALLATION

1. Lay the VStream Windscreen on a clean work surface and install four Rubber Grommets (2) into the mounting holes. **Figure 1**

2. Lay new VStream Windscreen **face down** and install top Bushings (5) into the upper holes, and lower Bushings (6) into the lower holes. **Figure 3**

3. Position Windscreen, with Rubber Grommets and Bushings installed, onto the mounting brackets of your motorcycle. Insert one M6 Screw (4) through one Cap (3) and through the Grommet and Bushing in the top left mount hole. Carefully thread it finger-tight into motorcycle's mount bracket. **Figure 3**

4. Repeat this procedure for the other three mount holes. Check position and alignment of windscreen. Tighten the four M6 screws with a 4mm Allen wrench.



Ask for Shield Wash™ and RainZip® at your local dealer or visit www.nationalcycle.com.

CLEANING AND MAINTENANCE

To clean the screen, wash with a clean soft cloth and plenty of warm water and, if necessary, a non-abrasive soap such as dishwashing liquid. Flannel or soft chamois make good cleaning cloths. **Paint, glue residue or grease removal:** Moisten cotton wad with naphtha or turpentine followed by a wash as above.

National Cycle **Shield Wash™** (N1401-01) makes a good daily cleaner and comes with a handy travel-size bottle. Shield Wash is safe for all windshields and helmet visors.

Do not clean polycarbonate in hot sun or high temperatures. Do not clean the screen with household glass cleaners.

Do not allow brake fluid, alcohol, or strong solvents to contact the screen.

RAIN REPELLENT

Do not use rain protective products made for glass. We recommend National Cycle's **RainZip®** (N1410-01) to keep your windshield clear in rainy weather.

VStream® Windscreen Patent no. 7,387,328

WARNING

Fahren Sie Ihr Motorrad niemals mit losen Zubehörteilen. Überprüfen Sie die Halterungen regelmäßig auf festen Sitz.

Die heutigen Motorräder sind mit einer ausreichenden Rahmensteifigkeit gebaut, um den moderaten Belastungen standzuhalten, die durch die absehbare Hinzufügung eines oder mehrerer Zubehörteile auf sie ausgeübt werden. Wenn ein oder mehrere Zubehörteile die Stabilität Ihres Motorrads beeinträchtigen, entfernen Sie sofort das / die Zubehörteil (e). Nehmen Sie kein Motorrad in Betrieb, das unsichere Fahreigenschaften aufweist.

Lassen Sie das Problem von erfahrenem Servicepersonal beheben, bevor Sie mit installiertem Zubehör fahren. Bei weiteren Fragen zu Handhabungsproblemen im Zusammenhang mit einem oder mehreren Zubehörteilen wenden Sie sich bitte an Ihren Händler, Motorradhersteller oder Zubehörhersteller.

Sonnenlicht, das von der inneren Krümmung der Windschutzscheibe reflektiert wird, kann zu bestimmten Tageszeiten zu einem extremen Wärmestau auf den Instrumenten des Motorrads führen und diese möglicherweise sogar zum Schmelzen bringen. Gehen Sie beim Parken vorsichtig vor, um dies zu vermeiden. Stellen Sie Ihr Motorrad in Richtung Sonne ab oder platzieren Sie einen undurchsichtigen Gegenstand über diesem Bereich.

National Cycle, Inc. PO Box 158 Maywood, IL 60153-0158 USA
708-343-0400 / Fax: 708-343-0625 / www.nationalcycle.com / info@nationalcycle.com